



Proposed for
RAMADA

The Geometrics Group
in Brushed Steel



*includes 24"
wire cover*

N8222DSWH-WC Brushed Steel 7" x 22"
Includes two on/off rocker switches on backplate



N8221DSWH-WC
Brushed Steel 4" x 7"
Includes on/off rocker switch
on backplate




W222DRWH Brushed Steel 29"
Includes single light with on/off rocker base
switch and electrical outlet

Also available: **WL2222DRWH** 29"
Includes Twin-light with two on/off
rocker base switches and two electrical
outlets



DP222DRWH Brushed Steel 26"
Includes Twin-light with two on/off rocker
base switches, electrical outlet and high
speed compatible phone jack

Also available: **W2E222DRWH** 26"
Includes Twin-light with two on/off rocker
base switches and two electrical outlets



PT1222DRWH
Brushed Steel 60"
Includes on/off push-
through socket



Proposed for
RAMADA



DP561RWH 27"

Brushed Steel w/Black

Includes on/off rocker base switch,
twin sockets, electrical outlet
and high speed compatible phone jack.

Also available: W2E561RWH
Same as above, except two
electrical outlets and no phone jack.



Now available:
GRT561DSWH 30"

Brushed Steel w/ Matte Black
Includes Twin-light with two on/off
rocker base switches with electrical outlet

New!



8562SWH-WC 4 1/2" x 22"

Brushed Steel w/Black

Includes two on/off rocker switches on backplate.



561SWH 28"

Brushed Steel w/Black

Includes on/off rocker base switch.

Also available: L2561SWH
Includes twin sockets and two on/off
rocker base switches.

Now available: W561SWH
Includes on/off rocker base switch
with electrical outlet


Now available: WL2561SWH
Includes Twin-light with two on/off
rocker base switches with electrical outlet



8561SWH-WC
4 1/2" x 6"

Brushed Steel w/Black

Includes on/off rocker
switch on backplate.



1561SWH 59"
Brushed Steel w/Black

Includes on/off push through
socket switch.



Proposed for
RAMADA®



B370DWH 29"
Polished Chrome
Includes on/off push-button base switch.

Also available: L2370DWH
Includes twin sockets and 3-way push-button base switch, (L, R, Both, None).



8371DWH-WC
4" x 6"
Polished Chrome
Includes on/off push-button switch on backplate.

includes 24"
wire cover



8372DWH-WC 4 1/2" x 22"
Polished Chrome
Includes 3-way push-button switch on backplate. (L, R, Both, None).

The
Crystal Ball
Collection

Made with durable chrome-plated steel and acrylic balls.



DP370DRWH 27"
Polished Chrome
Includes 3-way push-button base switch, (L, R, Both, None), twin sockets, electrical outlet and high speed compatible phone jack.



WDP370DRWH 27"
Polished Chrome
Includes twin sockets and 3-way push-button base switch, (L, R, Both, None), and *three* electrical outlets.



PT1370DWH 62"
Polished Chrome
Includes on/off push through socket switch.